




FULL MOTION TV WALL MOUNT | FM55M18 INSTALLATION GUIDE


RECOMMENDED FOR DISPLAYS 19" - 42"

VESA: 75x75 / 100x100 / 200x100 / 200x200 / 300x300 / 400x200 / 400x400 | Max Weight: 55 lbs. | Max Extension: 18"

TOOLS NEEDED




INCLUDED HARDWARE



ID	Qty.	Description	ID	Qty.	Description
1	1	Bracket	D	4	φ 18 × φ 8.5 × 10 spacer
2	1	Wall plate	E	4	M6 washer
A	4	M4*20mm bolt	F	2	M8 washer
B	4	M6*25mm bolt	G	2	φ 8 × 50 wall anchor
C	4	M8*25mm bolt	H	2	St8 x 65 bolt


1 TO INSTALL ON A WOOD STUD WALL

Locate the wood wall studs with a stud finder (not included). Position the wall plate (2) and mark the mounting holes. Drill holes and attach the wall plate (2), using washers (F) and bolts (H).



TO INSTALL ON A CONCRETE WALL


Position the wall plate (2) and mark mounting holes. Drill holes, insert the wall anchors (G), then attach the wall plate (2), using washers (F) and bolts (H).




2 Attach the bracket to the back of the display, using washers (E) and bolts (A, B, or C).

For displays with VESA 300x300mm, 400x200mm, and 400x400mm mounting pattern, use the four supplied extensions.

For curved TVs, use the four supplied spacers (D).



3 Attach the TV plate to the wall mount arm and tighten pre-installed hinge screws.



Caution: To avoid damage to your TV, use the shortest screw and spacer combination with adequate threads to secure your TV.